

EASY INSTALLS JUST GOT EASIER

Save time and money knowing the easy-to-install NAPA® Belden® Edge Premium Spark Plug Wires come ready straight out of the box. Our new enhanced product line is designed to be an industry leader and do wonders for your bottom line.



Purchase the NAPA® Belden® Edge steel welded cabinet and we will stock it full of premium spark plug wire sets and popular COP boots for **FREE**.



Belden EDGE
PREMIUM SPARK PLUG WIRES



ECHLIN

NAPA BELDEN EDGE WIRE CABINET COMPLETE WITH MERCHANDISE (#770703)

| PART # | QTY | DESCRIPTION | APPLICATIONS |
|--------|-----|-------------|---|
| 700950 | 1 | Wire Set | Buick 07-97; Chevrolet 05-00; Pontiac 07-97 |
| 700949 | 1 | Wire Set | Buick (Lesabre, Park Avenue, Riviera) 00-95; Oldsmobile 98, Delta 88, LSS, Regency) 99-95; Bonneville 00-95 |
| 700444 | 1 | Wire Set | Jeep (Cherokee, Comanche, Grand Cherokee, Wrangler) 99-91 |
| 700112 | 1 | Wire Set | Chrysler Pacifica 06-05; Town & Country 06-01; Voyager 03-01; Dodge Caravan 06-01; Grand Caravan 06-01 |
| 700791 | 1 | Wire Set | Buick (Century, Regal, Skylark) 99-94; Chevrolet (Beretta, Corsica, Lumina, Lumina APV, Malibu, Monte Carlo, Venture) 99-94; Oldsmobile (Achieva, Alero, Ciera, Cutlass, Cutlass Ciera, Cutlass Supreme, Silhouette) 99-94; Pontiac (Grand Am, Grand Prix, Montana, Transport) 99-94 |
| 700955 | 1 | Wire Set | Cadillac Escalade 00-99; Chevrolet (C1500, C2500, C3500, K1500, K2500, K3500 Pickup & Suburban, Express 1500, 2500, 3500, G10, G20, G30, G2500, G3500, P30 Van, Tahoe) 99-96; GMC (C1500, C2500, C3500, K1500, K2500, K3500 Pickup & Suburban, G15/G1500, G25/G2500, G35/G3500, P35/P3500 Van, Savana 2500, 3500, Yukon) 02-96 |
| 700100 | 1 | Wire Set | Dodge B1500 Van 98; B2500 Van 98; B3500 Van 98; Dakota 03-98; Durango 03-98; Ram 1500 Pickup 03-98; Ram 1500 Van 03-99; Ram 2500 Pickup 02-98; Ram 2500 Van 03-99; Ram 3500 Pickup 02-98; Ram 3500 Van 03-99 |
| 700989 | 1 | Wire Set | Cadillac Escalade 06-02; Chevrolet Avalanche 1500 06-02; P30 Van 99-98; Silverado 1500 HD 07-01; Silverado 2500 04-99; Silverado 2500 HD 07-01; Silverado 3500 07-01; Suburban 1500 06-00; Suburban 2500 06-00; Tahoe 06-00; GMC P35/P3500 Van 99-98; Sierra 1500 07-99; Sierra 1500 HD 07-01; Sierra 2500 04-99; Sierra 2500 HD 07-01; Sierra 3500 07-01; Sierra C3 01; Sierra Denali 07-02; Yukon 06-00; Yukon Denali 06-05; Yukon Denali XL 06-05; Yukon XL 1500 06-00; Yukon XL 2500 06-00; Hummer H2 07-03 |
| 700345 | 1 | Wire Set | Buick Century 05-00, Rendezvous 05-02 |
| 700540 | 1 | Wire Set | Chevrolet (Astro, Blazer, Pickup, Express, Van) 05-98; GMC (Pickup, Van, Jimmy, Safari, Savana, Sonoma) 05-98; Isuzu Hombre 00-98, Oldsmobile Bravada 01-98 |
| 700385 | 1 | Wire Set | AM General Hummer 96-95; Chevrolet (Blazer, C1500, C2500, C3500 Pickup & Suburban, G10, G20, G30 Van, K1500, K2500, K3500 Pickup, P20, P30 Van, R10, R20, R30, V1500, V20, V2500, V30, V3500 Pickup & Suburban) 93-87; GMC (C1500, C2500, C3500, K1500, K2500, K3500, R1500, R2500, R3500, V1500, V2500, V3500 Pickup & Suburban, G35/G3500 Van, Jimmy, Yukon) 93-87 |
| 700789 | 1 | Wire Set | Chevrolet (Blazer, C1500, C2500, C3500, K1500, K2500, K3500 Pickup & Suburban, Tahoe) 95-94; GMC (C1500, C2500, C3500, K1500, K2500, K3500 Pickup & Suburban, Yukon) 95-94 |

CABINET ALSO INCLUDES 1 COP BOOT ASSORTMENT WITH FITTED ASSORTMENT TRAY (#770305)

| | | | |
|--------|----|----------|--|
| 702418 | 10 | COP Boot | Ford Distributorless Coil Boot 4.6L, 5.4L Engines 08-97 |
| 702460 | 10 | COP Boot | Ford Mustang, F series Pick Up V10 6.8L and V8 5.4L 06-05 SOHC |
| 702428 | 6 | COP Boot | Ford Taurus E, Sable ME, V6 3.0S 24V DOHC 2007-04; Ford Escape 3.0-1 07-01 |
| 702421 | 6 | COP Boot | Jeep Cherokee, Grand Cherokee 4.0S 06-00 |
| 702423 | 6 | COP Boot | Chevy Colorado 4 cyl. 2.8i, 5 cyl. 3.5L 06-04, Chevy Trailblazer, GMC Canyon, Envoy, Olds Bravada 6 cyl. 4.2X 06 -02 |
| 702429 | 6 | COP Boot | Chrysler Concorde, Dodge Intrepid 2.7R 08-98 |
| 702424 | 4 | COP Boot | Saturn 2.2L 07-00; Chevrolet Cavalier, Malibu, Cobalt, HHR 2.2L 06-00; Oldsmobile Alero, Pontiac Sunfire, Grand Am, Pursuit 2.2L 06-02 |

- Cabinet offers 3 additional slots that can be used to customize additional assortment trays
- Cabinet designed to accommodate rolls of popular gauge primary wire (sold separately)
- Optional cabinet assortment with tray:
Wire Pigtail and Socket #770307 (sold separately)
- Optional cabinet assortment:
Primary Wire #770308 (sold separately)
- Empty assortment trays:
Balkamp #770208 - 16 divided slots (sold separately)
Balkamp #770201 - 32 divided slots (sold separately)



▶ #770305 (included)



▶ Wire Pigtail and Socket Assortment #770307 (sold separately)



▶ Primary Wire Assortment #770308 (sold separately)

Contact your NAPA® Under Hood DSM for more information today!



Belden® EDGE
PREMIUM SPARK PLUG WIRES